


HOW TO REMOVE THE MAGNET AT THE BACK OF SMART HOTEL DOOR BELL PANEL


(So that it will not make noise)




1- Unscrew all the sides of the Door Bell Panel




2- Remove the back cover of the Door Bell Panel




3- Push using screw driver between the PCB and the back cover lock to separate the PCB and the back cover.




4- Then the back cover and PCB is separated.



5- At the back cover, push the magnet using the screw driver.



6- Only remove the **one magnet on the corner near to USB Upgrade**, so that it will not make noise.



7- Once the magnet is removed. We can return back the cover of Hotel Door Bell Panel and screw it again. Now its done.

